CABINET PARTS

REFRIGERATOR

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2318584	Use & Care Guide
	2305869	Service & Wiring Sheet
	2318919	Energy Guide
	2220407	Modular Icemaker Service Sheet
	2261037	Instruction Sheet, Door Removal
2	2174748	Front Roller (2)
3	3400517	Screw
4	2196236	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
8	2260507	Housing, Water Filter
9	2209697	Shim (2)
10	2203770	Hinge Top, FC
11	2203771	Hinge Top, RC
13		Hinge Cover, FC
	2203407W	White
	2203407T	Biscuit
	2203407B	Black
14	2304322	Hinge Bottom (2)
15		Filler, Wrapper
	2196094	White
	2196150	Biscuit
	2196097	Black
16		Grille
	2260501W	White
	2260501T	Biscuit
	2260501B	Black
17	489497	Screw
18	489464	Screw
19	940139	Drain Fitting
20	1108438	Extension Tube
21	1108439	Clip, Drain Tube
22	4396841	Water Filter
23	2200455	Cover, Unit
24		Hinge Cover, RC
	2203408W	White
	2203408T	Biscuit
	2203408B	Black
25	549193	Clamp, Service Cord
26	489084	Screw
27	2155311	Door Closer, Lower Cam (2)
28	489483	Screw
29	489500	Screw
30		Cap, Water Filter
	2260502W	White
	2260502T	Biscuit
	2260502B	Black
31		Cabinet (Not A Serviceable Part
32	8281227	Screw
33	3400113	Screw (4)
34		Button, Water Filter
	2260503W	White
	2260503T	Biscuit
	2260503B	Black
35	2260519	Block, Housing Support
36	2255012	Tube, Filter Outlet
37	2304697	Tube, Filter Inlet

REFRIGERATOR LINER PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide Meat Pan Control
4	2257741	Louver
5	2256037	Wire Harness, Dual Crisper
9	2206270	Shelf Ladder
10	489478	Screw
11	W10004810	Screw (2)
12	2256035	Bracket, Dual Crisper Light
13	1123919	Bracket Retainer
14	489290	Screw
15	2209753	Air Diffuser Assembly
16	2152019	Air Diffuser Cover
17	2150331	Cover, Conduit
18	2162085	Socket
19	2256126	Reservoir
20	2255743	Light Bulb
21	2209769	Light Lens
22	488280	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)



Illus. No.	Part No.	DESCRIPTION
1	2188695	Shelf Assembly, Spillguard (2)
2	2188655	Snack Bin
3	2209698	Cover, Crisper
4	2196485	Stud Assembly
5	2174150	Glass, Cover
6	2179259	Glass, Cover
7	3400894	Screw
8	2311726	Cover, Meat Pan
10	2188652	Crisper Pan
11	2179343	Front, Crisper Pan
12	2179342	Slide, Humidity Control
13	2255593	Trim, Handle
14	2188654	Meat Pan
18	2179350	Deflector
19	2255592	Trim, Handle
22	2206347	Shelf, Snack Bin
24	2179243	Trim, Handle

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
7		Track, Basket−Dual
	2301291	Right
	2301292	Left
9	2211743K	Shelf, Slide Out Lower (2)
13		Shelf Track
	2301289	Right Side
	2301290	Left Side
14	2212343K	Shelf (2)
15	2216111	Freezer Bin
16	W10004810	Screw (8)
17	842534	Clip, Air Duct (2)
19	2255572	Cover, Emitter
22	2198635	Spring
23	2198634	Pin
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2255589	Cover, Ice Maker
28	2212321	Slide, Ice Maker
29	489478	Screw
30	489214	Screw
32	2155597	Light Socket
33	2255743	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2255558	Cover, Receiver
37	2255562	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
41	2212376	Light Lens
42	2198641	Bracket, Ice Maker Cover
45		Ladder
	2212315	Left Side
	2212316	Right Side
46	2219878	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1	2212302	Ice Bin
2	2255577	Crusher Bin
3	2258224	Auger
4	2258220	Washer
5	1119007	Spacer, Flat (4)
6	2255461	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2188918	Coupling
17	8281164	Screw
18	3400065	Screw
20	2255578	Latch, Bin
21	2198608	Spring, Latch
23	8281163	Screw
24	2188919	Holder
26	2198628	Seal
30	2188916	Drive Shaft
31	2256154	Enclosure, Motor
32	2315546	Dispenser, Motor
33	2212305	Cover
36	2315559	Sleeve, Coupling
100	2315938	Ice Container (Complete)

REFRIGERATOR DOOR PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #8)
	2307101W	White
	2307101T	Biscuit
	2307101B	Black
	2307101LG	Stainless VCM
3	2256101	Door, Compartment
4	2156022	Trivet, Shelf
5	8533920	Screw
6	2304235K	Door Bin (3)
7	2308091	Thimble, Top
8		Door Gasket, Magnetic
	2221300	Mist Beige
	2221311	Black
9		Handle
	2313345W	White
	2313345T	Biscuit
	2313345B	Black
10	3400012	Screw
11	2255411	Clip
12	2255121	Nameplate
14	2182178	Door Closer, Upper Cam
15	489420	Screw
16		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
20	489491	Screw (4)

FREEZER DOOR PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item #8 And Dispenser Front Parts)
	2315972W	White
	2315972T	Biscuit
	2315972B	Black
	2315972LG	Stainless VCM
2		Handle
	2313345W	White
	2313345T	Biscuit
	2313345B	Black
3	488500	Screw
4	8533920	Screw
5	2255411	Clip
6	2313198K	Trim, Door (3)
7	2195917	Endcap (6)
8		Door Gasket, Magnetic
	2221301	Mist Beige
	2221312	Black
9	2212375	Trim, Door Shelf
10	3400012	Screw
11	2207225	Wire Harness
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
15	2304896	Safety Barrier
16	2154473	Connector
17	2182181	Thimble, Top
21	489491	Screw (4)

DISPENSER FRONT PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2304772	Spring, Torsion
5	2196195	Pin
6	2180353	Door, Ice
7	2304355	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206671W	White
	2206671T	Biscuit
	2206671B	Black
10	2304317	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2255431W	White
	2255431T	Biscuit
	2255431B	Black
12	2180224	Guide, Ice
13	2180200	Socket
14	2162361	Switch
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2255432W	White
	2255432T	Biscuit
	2255432B	Black
18		Switch Assembly (Not Available, Order #23)
19		Overlay, Front Cover (Not Available Order #23)
20	2187406	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 19, 20 & 21)
	2318558W	White
	2318558T	Biscuit
	2318558B	Black
24	625834	Spacer, Switch (2)
25	2195051	Strain Relief
26	2304673	Bracket, Dispenser
27	3400896	Screw

UNIT PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
2	2225834	Fan, Blade
3	2304902	Condenser Assembly
4	489464	Screw
5	2216914	Clip, Condenser
6	8533993	Screw
7	2304288	Heat Shield And Drain Pan
8	2205764	Tube Suction
10	2261599	Tube, Condenser to Heat Loop
12	4387731	Cover (Service Only)
13	2187145	Overload (Service Only)
14	2161324	Clip, Defrost Heater
15	2183454	Relay (Service Only)
16	2188829	Start−Device, Combination (Start Relay and Overload for Production Compressor Only)
17		Capacitor
	2169373	Production
	1118576	Service
18	2223314	Clip, Retaining
19	4387765	Wire, Capacitor (Service Only)
20	2304898	Unit Cover, Bottom
21	489396	Clip
22	2188822	Evaporator
24	2188874	Motor, Fan
25	1105523	Tray, Evaporator
26	2187783	Harness, Unit
27		Drier
	2319825	Production
	4387019	Service
28	2212191	Compressor (Includes Items 12, 13, 15, 17, 19 & 27)
30	2304903	Frame, Unit Mounting
32	2181929	Bracket, Fan Motor
33	2188174	Heater, Defrost
34	2304287	Clip
37	489373	Screw
39		Grommet (4)
	1100826	Production
	4387558	Service
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat
48	2149718	Unit Mounting Rail
49	8281232	Screw
50	2260516	Guard, Fan
51	2161302	Sleeve
53	489427	Screw
55	489478	Screw
59	2208280	Clip, Wire & Tube
63	2209709	Connector, Water Tube

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

5.0 oz.
(R−134)

ICEMAKER PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256095	Fitting, Water Tube
5	628379	Clip, Fuse
9	489478	Screw
10	2304834	Filter Valve Asm
16	489385	Clip, Tube
18	2174358	Cover
19	488649	Screw
20	2212351	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Cup−Water Fill
23	2212320	Ejector
24	2212318	Ice Striper
25	2194712	Support
26	2315522	Retainer, Thermostat
27	627985	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
30	489276	Screw
32	2187484	Harness, Wiring
33	2212317	Bracket, Icemaker Mounting
35	626680	Module Assembly (Includes Items 37 & 38)
37		Motor (Not Serviced, Order #35)
38	489136	Screw
100	2212352	Complete Icemaker Assembly

CONTROL PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03

(White) (Biscuit) (Black) (Stainless VCM)



Illus. No.	Part No.	DESCRIPTION
1	8201785	Control Box
2	2172931	Heat Shield
3	3196537	Screw (4)
4	2149705	Light Switch
5	2196001	Tube Barrier
6	2304069	Electronic Control
7	489398	Screw (2)
8	940014	Hole Plug
9	2315562	Thermostat
10	2181741	Slide, Air Control
11	2172906	Grommet
12	2161466	Slide, Thermostat
13	2200096	Cover, Indicator Light
14	2179920	Light Bar (RC)
15	2161306	Pivot Arm
16	627068	Screw
17	2162085	Light Socket
18	2161307	Connecting Rod, Short
19	2255743	Light Bulb
20	2212237	Control Box Harness
21	1115374	Clip, Wiring
22	1115375	Clip, Wiring
23	2161308	Connecting Rod
24	489391	Fastener, Push−On
25	2315154	Escutcheon, Control Box
26	2179921	Light Bar (FC)
27	2175513	Window
28	2213462	LED Assembly
29	489203	Spring Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)



Illus. No.	Part No.	DESCRIPTION
1	2182119	Fan Scroll
2	2155590	Retainer, Fan Motor
4	2313359	Air Duct, Upper
5	2212313	Air Duct Freezer
6	2319914	Bi−Metal, Defrost
7	2315549	Fan Motor
8	2169142	Fan Blade
9	2304241	Gasket, Evaporator Cover (2)
10	2176759	Fan Grommet (2)
12	2310237	Harness, Fan Evaporator (Includes #6)
13	2155788	Gasket, Fan Scroll
14	2172840	Wire Tie
16	2203875	Gasket
17	2304908	Cover, Evaporator (Includes #9)
18	8281159	Screw (6)
21	489478	Screw
22	2203595	Support, R.S
23	2203596	Support, L.S

OPTIONAL PARTS (NOT INCLUDED)

For Models: ED2FHAXSQ03, ED2FHAXST03, ED2FHAXSB03, ED2FHAXSL03
(White) (Biscuit) (Black) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION

PAINT, PRESSURIZED SPRAY (12 oz.)

*350942	Primer, White
*350939	Black
*350930	White

PAINT, TOUCH−UP (1/2oz.)

72017	White
72032	Black

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

PAINT, BULK (1 qt.)

799340	Black
799344	White

Miscellaneous

212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4 x 108")
505587	Sealer, Mastic (1 Qt.)
503695	Cork, Sealer (1/4 Pound)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1−1/4 Oz.)
799833	Kit, Evaporator Repair (Aluminum Epoxy)
833938	Kit, Terminal Connector

TORX SCREW WRENCH

1117510	Torx Key

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST